WeighRite

1-888-225-6753

Setting Up WeighRite

J-Box

LED Display

Valley Ag Sw

Scale Ports

1 = Loadcell
2 = Com Port
3 = Printer
4 = Not Used
5 = Remote Display
6 = Not Used
7 = Power

Receiver Box

Modem

Printer

13V Power Supply